

ABS Headliner Installation Instructions

1973-75 Plymouth Valiant / Dodge Dart

2 Door Hard Top

Part Number AFH35

Please read these instructions completely through before starting the installation.

Note: All ABS Headliner boards come with pre-cut holes in the board for dome lights, visor bracket openings, etc. Fabric will cover the entire board. Once you choose which openings you need, using a razor knife, cut an "X" in the center of each opening and fold back the material that can be glued or taped to the back side of the board. This will give each opening a clean appearance.

Your headliner board is pre-cut with dome light opening and sunvisor opening cut outs. There may be some other holes pre-drilled for ease of installation.

If your board is pre-covered the cut outs are on the back side only. When cutting the covered side to access the cut outs please make an "X" cut in the center of the cut out. This will allow you to be able to fold back the material to give the opening a clean appearance on the visible side.

1. Remove sunvisors, rear dome light & plastic trim moldings around the headliner. If present the old headliner should be removed and discarded. Note: The old headliner can be used as a reference in case there are some adjustments to be made.
2. Install headliner with the sunvisors loosely installed to hold the headliner in place in case there are some minor adjustments. Then re-attach the dome light and trim moldings. Once the headliner is in position, tighten down the sunvisor brackets.