

Pressboard Headliner Installation Instructions 1973-79 and 1980-86 Ford Super Cab Truck

Note: All Pressboard Headliner boards come with pre-cut holes in the board for dome lights, visor bracket openings, etc. Fabric will cover the entire board. Once you choose which openings you need, using a razor knife, cut an "X" in the center of each opening and fold back the material that can be glued or taped to the back side of the board. This will give each opening a clean appearance.

The headliner board will arrive folded in half. Included with the headliner board will be another cardboard strengthener with special net bond tape on one side.

Unfold the board, lay flat with material side down on clean surface. Cut and apply strengtheners as in picture and let sit for 24 hours to get a good bond.



Please read these instructions completely through before starting the installation.

Your headliner board is pre-cut with dome light opening and sun visor opening cut outs. There may be some other holes pre-drilled for ease of installation. Headliner also has score lines in the board to bend the sides and rear. Prior to installation bend the sides and rear carefully little by little to avoid damage.

1. Remove sun visors, rear dome light & plastic trim moldings around the headliner. If present the old headliner should be removed and discarded. Note: The old headliner can be used as a reference in case there are some adjustments to be made.
2. Install headliner with the sun visors loosely installed to hold the headliner in place in case there are some minor adjustments. Then re-attach the dome light and trim moldings. Once the headliner is in position, tighten down the sun visor brackets.